MC-049C CIRCUIT DIAGRAM 041123

IC11
VCT49xyI

IC601
LA42071 (7WX1)
LA42072 (7WX2)
LA42152 (15WX2)

IC12
24C04/16

IC801
LA4285/LA4287/LA4288

IC301
TDA4863A

CPT BOARD

PIP BOARD

SIDE A/V BOARD
6870VS1020A

PJ202
FRONT AV(AV2)

PJ211
DVD

JK201 SCART1 FULL SCART or PHONO JACK
(A/V1)

HOT

INNER PIN CIRCUIT

NOTICE

Since this is basic circuit diagram the value of components and some partial connection are subject to be changed for improvement without notice.

The components marked ⚠ conform to VDE or IEC guide-lines and are essential for safe operation of the TV receiver.
While those marked ⚠ are required for correct operation.
Use specified parts only when replacing.

Value of resistor. capacitor and inductor

1. Resistances are shown in ohm. K=1,000, M=1,000,000
2. Unless otherwise noted in schematic. all capacitor values less than 1 are expressed in m=0 and the values more than 1 in pF.
3. Unless otherwise noted in schematic. all inductor values more than 1 are expressed in uH and the values less than 1 in mH=1mH.

Observation of voltages and waveforms

1. Voltages read with VTVM from point to chassis ground. line voltage is 230V/220V voltage/signal pattern is colour-bar.
2. The schematic shown is representative only.
3. All waveforms are taken using a wide band oscilloscope and a low capacity probe.
4. Check FINE TUNING AGC CONTRAST BRIGHTNESS and COLOUR controls for best picture. Make sure that COLOUR and BRIGHTNESS are in mid-point and CONTRAST is in MAX.
5. Waveforms are taken using a standard colour signal.

COMPONENT	RL	RE	RT	RJ	REMARKS

P/NO: 3854VA0204A - S1
2004.12.15

MC-049C CIRCUIT



IT DIAGRAM 041123



COMPONENT	RL	RE	RT	RJ	REMARKS